IP Link® Device Interface
Ethernet Communication Sheet

This document provides additional assistance with wiring your Extron IP Link enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific Extron IP Link enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type:	Audio Processor
Manufacturer:	QSC
Firmware Version:	N/A
Model(s):	DCP 300

Minimum Software and Firmware Requirements:

IP Link Compiler	IP Link Firmware	GC Version
1.4.0	1.15	3.0.4

Version History:

Driver Version	Date	Notes
1	3/2/2011	Initial version.

Driver Notes:

Please note that this driver will only work password with length of 3 only. Any device with password that is longer or shorter than 3 will not work.

Control Commands & States:

Active Audio Preset	1 to 16	
Active Control Preset	None	1 to 32
Master Amp Power	On	Off
Master Mute	On	Off
Master Volume	-90 to 10 in steps of 1	

Status Available:

Active Audio Preset	1 to 16		
Active Control Preset	None	1 to 32	
Connection Status	Connected	Disconnected	
Master Amp Over Temp	Normal	Temp High	Status Unavailable
Master Amp Power	On	Off	
Master Amp Protect Status	Normal	Protect	Status Unavailable
Master Mute	On	Off	
Master Volume	-90 to 10 in steps of 1		

IP Link® Device Interface
Ethernet Communication Sheet

Network communication:

When configuring the Ethernet driver, be sure device settings match that of the GC configuration.

Port Type:	Ethernet
Logon Credentials Supported:	Yes
Default Password:	qsc
Default Port:	4446
Multi-Connection Capable:	Yes
Port Changeable:	No

Ethernet Driver Configuration Description:

Please refer to user manual for settings and changes to the network communication parameters such as: User Name, and Passwords.

Notes for the Device: